



# Ocean Twin Bed Conversion Instruction Sheet

Read All Instructions Before Assembling. Keep Instructions For Future Use.

**(A PHILLIPS HEAD SCREWDRIVER AND A FLAT-HEAD SCREWDRIVER IS REQUIRED)**

## ITEMS INCL. W/TWIN KIT

(2) Short Posts	(1) Youth Brace Rail	(10) Cam Locks
(2) Twin Top Caps	(1) Support Bracket Kit	(10) Cam Stud Bolts
(2) Adult Rails	(32) 3/4" Wood Screws	(1) Allen Wrench

Model \_\_\_\_\_ MFG. Date \_\_\_\_\_ P.O. # \_\_\_\_\_

**Step 1:** Remove the Mattress Support, Front Frame and Back Frame from the Crib.

**Step 2:** Take the two Front Post and two Back Post off the Side Panels.

**Step 3:** You will need to turn one Side Panel 90 degrees. Attach the two Rear Posts to the Side Panel by using the four 60mm Bolts and the Allen Wrench Do Not tighten the bolts At this time. You will now need to attach the Bottom Brace between the two Rear Post, below the Side Panel. You will need to attach this Bottom Brace by using two of the Cam Studs and Cam Locks that were provided with the Crib Hardware.



**Step 4:** You will use the two Short Post provided in the Twin Conversion Kit and the other Side Panel to make the Footboard for the Twin Bed. Attach the two Short Post to the Side Panel with the four 60mm Bolts and the Allen Wrench.

**Step 5:** To attach the Twin Top caps depends on which type of hardware you have with your product.

- Using Cam Studs and Cam Locks:

Place the Twin Top Caps with the Cam Studs facing down into the pre-drilled holes on the top of the Front and Back Posts. Take a Cam Lock, with the arrow facing the feed of the Cam Stud into the holes in the Posts underneath the Top Cap. Tighten down the Cam Locks with the Allen Wrench.

- Using 20mm Bolts:

Place the Top Cap in position on top of the assembled headboard and foot board frames. Secure in place using two 20mm bolts, two washers and the open end wrench. You will need to do this for both Top Caps.

**Step 6:** Attach the Adult Rails included in the Twin Bed Conversion Kit. You will need to screw the Cam Studs Into the bottom insert in each post. Slide the rails up on the Cam Studs by inserting the Cam Studs into The holes located in the ends of the wooden Adult Rails. When both rails are slid against the posts you Need to insert the Cam Locks into the holes on the inside of the rails. Tighten using your Allen Wrench. Make sure that the Cleats are on the Upper End of the Adult Rail.  
(See Picture)



DO NOT substitute parts. Contact 1-800-TEL-CRIB for replacement parts and instructional literature if needed.