



# Convertible "Generation Next™" Crib Instruction Sheet


Read All Instructions Before Assembling Crib. Keep Instructions For Future Use.

## PARTS LIST (A PHILLIPS HEAD SCREWDRIVER AND A FLAT-HEAD SCREWDRIVER IS REQUIRED)


<b>BF)</b>	1	Back Frame (largest)	<b>THS)</b>	4	Fully Threaded Studs
<b>FF)</b>	1	Front Frame (with Drop Gate)	<b>CL)</b>	4	Cam Locks
<b>SF)</b>	2	Side Frames	<b>CS)</b>	4	Cam Stud Bolts
<b>FP)</b>	2	Front Corner Posts (with Strike Plate)	<b>B60)</b>	8	60mm Bolts
<b>RP)</b>	2	Rear Corner Posts (without Strike Plate)	<b>B80)</b>	4	80mm Bolts
<b>DG)</b>	1	Drop Gate (attached to Front Frame)	<b>TL)</b>	2	Trigger Latches (attached to Drop Gate)
<b>WD)</b>	2	Large Wooden Dowel with 2 holes (51 <sup>3</sup> / <sub>8</sub> " long)	<b>SP)</b>	2	Strike Plates (attached to front Corner Posts)
<b>ES)</b>	2	End Skirts	<b>H)</b>	1	Hinge (attaches Drop Gate to Front Frame)
<b>MS)</b>	1	Mattress Support (Metal Spring)	<b>HW)</b>	1	Hex Wrench (included)
<b>B1)</b>	4	Small 1" Spring Bolts	<b>AW)</b>	1	Allen Wrench (included)
<b>GP)</b>	16	1 <sup>1</sup> / <sub>4</sub> " Gate Pins	<b>ABR)</b>	2	Adult Bed Rails (not included with the Crib)




TL) Trigger Latch



BF) Back Frame






FF) Front Frame




SF) Side Frame



SP) Strike Plates




HW) Hex Wrench



MS) Mattress Support




B1) Small Spring Bolts



GP) 1<sup>1</sup>/<sub>4</sub> inch Gate Pin



AW) Allen Wrench



SP) Strike Plates

FP) Front Corner Posts

RP) Rear Corner Posts

• No-Insert Hole    ⊙ Rosette  
+ Hole With Metal Insert




THS) Fully Threaded Stud




CL) Cam Lock



CS) Cam Stud Bolt



ABR) Adult Bed



ABR End View

**FOR FUTURE USE AND REFERENCE**  
**RETAIN THIS INSTRUCTION SHEET AND THE CRIB TOOLS IN THE ORIGINAL SACK**  
**AND SECURE IT TO THE SPRING UNDER THE MATTRESS WITH PLASTIC TIES.**

**CARE INSTRUCTIONS:** The natural warmth of wood is a lasting value. Character marks, checking and grain variations are part of the beauty of wood and, therefore, should not be a concern. If treated with care, this solid wood product will last you for many years to come. Once every week, wipe your Baby's Dream furniture with Pledge®, lemon oil or other similar wood treatment products. If you encounter any roughness in the finish of your new crib, fold a piece of regular white paper—not tissue or newspaper—and rub it gently against the surface until the desired smoothness is achieved. If refinishing, use a non-toxic finish specified for children's products. Let dry, sand with a very fine product such as folded paper or dishing washing sponge and, finally, apply water-based baby-safe lacquer for the perfect matching shine.

**WARNING!**

To insure your child's safety and for your own peace of mind, be sure to follow instructions properly. Failure to follow these warnings and assembly instructions could result in serious injury or death. Before each usage or assembly, inspect the crib for damaged hardware, loose joints, missing parts or sharp edges.

- ✓ **DO NOT** use the crib if any parts are missing or broken.
- ✓ **DO NOT** substitute parts. Ask your dealer or write to Baby's Dream Furniture for replacement parts and instructional literature if needed.
- ✓ Make sure that all bolts and screws are properly tightened. **DO NOT** over- or under-tighten.
- ✓ **AVOID STRANGULATION:** As soon as an infant can sit or stand up, close the crib gate permanently.
- ✓ **DO NOT** place the crib near a window where cords from blinds or drapes may strangle a child.
- ✓ **DO NOT** tie pacifiers, necklaces or any other items around a child's neck or on the crib parts.


**WARNING!**

Strings can cause strangulation! Do not place items with string around a child's neck, such as hood strings or pacifier cords. Do not suspend strings over a crib or attach string toys.

- ✓ **NEVER** use plastic shopping bags or other film as mattress covers, because they can cause suffocation.
- ✓ For a newborn, adjust the spring on the highest level of the Height Adjuster and open the gate for easy access.
- ✓ **DO NOT** leave a child in a crib with an open gate. Be sure the gate is closed and locked in position whenever the child is in the crib. After closing the gate, make sure the latches are secure.
- ✓ The child must be seated at the rear of the crib when lowering or raising the gate or rail.
- ✓ As your child grows, adjust the height of the spring down so that he/she cannot pull himself/herself out of the crib. When the child is able to pull to a standing position, set the mattress to the lowest position and remove bumper pads, large toys and other objects that could serve as steps for climbing out. When the child is able to climb out or reaches the height of 35" (90cm), the bed should no longer be used in the form of a crib. You can continue to use this crib as a youth or toddler bed for another 2 to 3 years by using the **Youth Bed Conversion Kit**.

**ANY MATTRESS USED IN THIS CRIB MUST BE AT LEAST 27<sup>1</sup>/<sub>4</sub>" X 51<sup>5</sup>/<sub>8</sub>" WITH A THICKNESS NOT EXCEEDING 6". DO NOT USE A WATER MATTRESS WITH THIS CRIB.**

This crib conforms to the applicable regulations promulgated by the Consumer Product Safety Commission.



This product may be covered by one or more of the following patents: D366,778; D366,970, 5,077,846 and other patents pending.




**BABY'S DREAM**  
FURNITURE, INC.

Buena Vista, GA 31803-0579  
www.babysdream.com



# CRIB ASSEMBLY INSTRUCTIONS

It is recommended that two people help assemble this Crib.



Step 1

**Step 1:** Tap in 2 Gate Pins (GP) into each end of an End Skirt (ES).


**Step 2:** Attach a Rear Corner Post (RP) a Front Corner Post (FP) to each end of a Side Frame (SF). Use a 80<sup>mm</sup> Bolt (B80) to attach the top of the post. Use a Cam Lock (CL) and a Cam Stud Bolt (CS) to attach the wide part of the post at the bottom. Drop the four End Skirt (ES) Gate Pins (GP) into the small holes on the front and back Corner Posts and tighten all bolts so that the End Skirt (ES) is secured.

**Note:** The 2 middle inserts on the edges of the Corner Posts are for height adjustment of Mattress Support Spring ONLY.

Step 2 & 3


**Step 3:** Repeat Step 1 and Step 2 for the other side of the crib.

**Step 4:** Place the Back Frame (BF) on the floor with the Headboard curving towards the floor. Place the right hand Side Frame (SF) perpendicular to the Back Frame (BF) and attach them to each other with two 60<sup>mm</sup> Bolts (B60).



Step 4 & 5


**Step 5:** Attach the Large Wooden Dowel (WD) to the bottom round part of the Rear Corner Posts (RP) with a Fully Threaded Stud (THS) and a Gate Pin (GP).  
NOTE: The Fully Threaded Stud (THS) simply fits inside a hole on the post.



Step 7 & 8


**Step 6:** Repeat Step 4 and Step 5 for the other side of the Crib. Place the left hand Side Frame (SF) perpendicular to the other side of the Back Frame (BF) and attach them to each other with two 60<sup>mm</sup> Bolts (B60). Drop the other Fully Threaded Stud (THS) into the left post.

**Step 7:** Stand the three-sided Crib upright by holding and raising the Back Frame (BF) from behind.



Step 9

**Step 8:** Attach the Large Wooden Dowels (WD) to the bottom round part of the Front Corner Posts (FP) with a Fully Threaded Stud (THS) and a Gate Pin (GP). **Note: Fully Threaded Stud (THS) simply fits inside a hole on the post.**




Step 10

**Step 9:** Place the Mattress Support Spring (MS) on the floor inside the Crib. Insert and turn two Small Spring Bolts (B1) into the Height Adjustment Inserts on the Rear Corner Posts (RP). Tighten all Small Spring Bolts (B1) at the end. Attach the front of the Mattress Support Spring (MS) to the Front Corner Posts (FP) with two Small Spring Bolts (B1).

**Step 10:** Attach the Front Frame (FF) to the rest of the Crib at the Front Corner Posts (FP) with four 60<sup>mm</sup> Bolts (B60).

## HOW TO ATTACH TWO PARTS WITH THE CAM AND STUD MECHANISM:


- (1) First turn the Cam Stud Bolt (CS) into the METAL INSERT of Part A and tighten firmly with a flat head screwdriver.
- (2) Then insert the round end of the Cam Stud Bolt (CS) (as it is attached to the first piece) into the hole at the edge of Part B.
- (3) Place the Cam Lock (CL) on the tip of a Phillips head screwdriver and insert it into the hole on the face of Part B. Make sure that the triangular pointer on the Cam Lock (CL) points towards the Cam Stud Bolt (CS) for easy fit.
- (4) Once the Cam Stud Bolt (CS) is fitted snugly inside the Cam Lock (CL), turn it 90° clockwise with the Phillips head screwdriver to lock.



# YOUTH BED ASSEMBLY INSTRUCTIONS

## STARTING FROM CRIB:

- Step 1:** Remove the Front Frame (**FF**) and leave the Front Corner Posts (**FP**) on the bed.
- Step 2:** Make sure that the Mattress Support Spring (**MS**) is secured to the lower Height Adjustment Insert on the four Corner Posts.
- Step 3:** Remove the Large Wooden Dowel (**WD**) from the lower back part of the Crib (between the rear Corner Posts). Remove the stud and pins.
- Step 4:** Attach the Large Wooden Dowel (**WD**) to the Front Corner Posts (**FP**) using two 60<sup>mm</sup> Bolts (**B60**).
- Step 5:** Remove the Strike Plates (**SP**) from the Front Corner Posts (**FP**).




Youth Bed

## STARTING FROM SCRATCH:

- Step 1:** Follow **Steps 1** through **6** of the Crib assembly instructions.
- Step 2:** Follow **Steps 2** through **5** of the above Youth Bed assembly instructions (starting from crib).

# YOUTH BED GUARD RAIL INSTRUCTIONS

- Step 1:** Use the above instructions to convert your **Generation Next Crib™** into a **Youth Bed**.
- Step 2:** Unscrew the Hinge (**H**) on the Front Frame (**FF**) and detach the Drop Gate (**DG**).
- Step 3:** Detach the two Trigger Latches (**TL**) from both ends of the Drop Gate (**DG**).
- Step 4:** Loosen the bolts on the Large Wooden Dowel (**WD**) connecting the Front Corner Posts (**FP**).
- Step 5:** Hammer in the Gate Pin (**GP**) <sup>3/4"</sup> deep into the pilot holes on the two ends of the Drop Gate (**DG**).
- Step 6:** Insert four Gate Pins (**GP**) on the Drop Gate (**DG**) into the four pilot holes on the inside of the four Corner Posts.
- Step 7:** It is vital to properly tighten the bolts on the Large Wooden Dowel (**WD**), because the Drop Gate (**DG**) is suspended between the posts by the Large Wooden Dowel only.




Youth Bed **With** Guard Rail

# FULL-SIZE BED ASSEMBLY INSTRUCTIONS

- Step 1:** Remove the Drop Gate (**DG**) from the Front Frame (**FF**) by unscrewing the Hinge (**H**).
- Step 2:** Remove the two Strike Plates (**SP**) from the Front Corner Posts (**FP**).
- Step 3:** Attach the Back Frame (**BF**) to the two Rear Corner Posts (**RP**) with four 60mm Bolts (**B60**).
- Step 4:** Attach the Front Frame (**FF**) to the two Front Corner Posts (**FP**) with four 60mm Bolts (**B60**).
- Step 5:** Attach the Large Wooden Dowel (**WD**) in between the bottom of the Front Corner Posts (**FP**), using Gate Pins (**GP**) and a Fully Threaded Stud (**THS**) at each end. Attach the Large Wooden Dowel (**WD**) in between the tops of the Front Corner Posts (**FP**) with a Gate Pin (**GP**) and a Fully Threaded Study (**THS**) at each end.
- Step 6:** Connect the Headboard and Footboard with solid wood Adult Bed Rails (**ABR**). Make sure that the mattress support cleats are on the upper end of the rails.

Adult Bed



**WD**) Large Wooden Dowel